How to set timer

You can set the timer to 60, 120 or 180 minutes.

- Double press the + button to set the timer to 60 min, double press again for 120 min, and again for 180 min. 60 min, 120 min, 180 min, clear timer setting.. it repeats this cycle.
- The corresponding light and a voice prompt will remind you of the timer set.

NOTE: In Bluetooth mode, if there's no device connected, the timer will not work. In white noise mode, the timer will always work.

How to use white noise

SnoozeBand Deluxe comes with built-in white noise, so you can enjoy relaxing audio even without a Bluetooth connection.

- 1 Double press the button to enter the White noise mode
- Short press the middle button to play/pause music
 Long press the + and button to switch between tracks
 Short press the + and button to adjust volume

NOTE: At anytime you can switch between the bluetooth and White noise mode by double pressing the – button.

In White noise mode, the bluetooth will be disconnected

Washing the SnoozeBand __

- 1 Carefully remove the components of the eyemask before washing
- 2 Hand or machine wash with cold water and air-dry

Precautions

- ★ DO NOT expose the product to liquids or moisture
- * DO NOT attempt to tamper with the product by dropping, disassembling, opening or scratching etc.
- ★ DO NOT store the product near acidic or alkaline material
- * Take out the headphones before washing
- ★ Keep the product away from fire and high temperatures
- * Keep the product away from children and animals
- ★ Note: when not used for 3-6 months, charge once.

Features

- ★ Built-in wireless speakers and microphone
- ★ Integrated white noise
- ★ Automatic shut-off timing function
- * Rechargeable through USBC cable

Specifications _

★ Wireless version: V5.2

★ Frequency: 2.402 GHz - 2.480 GHz

* Transmission range: 20m/66Ft

* Rated power: RMS 10mW x 2

* Speaker unit: 32 /30mm

* Battery: 300mAh rechargeable Li-polymer battery

★ Play time: 10-13 hours

* Charge time: 2 hours - please do not overcharge





Control Buttons _

Power On/Off	▶II > 3 s	Press and hold for 3 seconds
Play/Pause Music	> 1	Press once when connected
Volume Up/Down	<u></u> +	Press once during music playback
Next Track	(+) x 1	Press and hold during music playback
Previous Track	_ x 1	Press and hold during music playback
Answer/End Phone Call	▶II) x 2	Quickly press twice
Set auto-timer switch off	+ x 2	Double click for power off in 1 hour, double click again for power off in 2 hours, double click again for 3 hours
Play White noise	_ x 2	Double click in quick succession to enter white noise mode
Enter Bluetooth mode	_ x 2	Double click at any time to switch between the White noise and Bluetooth mode



Turning On/Off _____






Press and hold for 3 seconds

Pairing with your device __

1 Turn on Bluetooth



Turn on the SnoozeBand





After paired successfully, the blue light will flash for 10 seconds. When switched on next time, it will automatically search for and attempt to connect with the last paired device. If you want to pair it with a new device, make sure it's disconnected from the previously paired device.

NOTE: To save power, it will switch off automatically if there's no Bluetooth connection for 3 minutes.

Charging

Make sure the device is switched off, open the zipper on the eye mask and you will see the USBC charging port.

- 1 Connect the Type C USB cable to the charging port and the other end into a power source with ~5V (eg. phone charger)
- The LED light will turn red whilst charging. It will turn blue as soon as the battery is fully charged (approx. 2 hours). Please do not overcharge as this might damage the battery over time.

LED Indicators _____

Status	Indicator
Bluetooth pairing mode	Flashing red/blue lights
Bluetooth connected	Blue light flashes for 10sec
White noise mode	Blue light flashes twice for 10sec
60min Timer	Solid red light for 10sec
120min Timer	Solid blue light for 10sec
180min Timer	Solid green light for 10sec
Timer cleared	Double flash green light
Charging/Charging complete	Solid red light/solid blue light

How to fasten the band

The Velcro is hidden away inside the fabric, to access it please flip the pocket at the end of the Snoozeband inside out fully. You are now able to secure the band to the most comfortable postion with the adjustable velcro strap. For storage/transport, please flip the velcro inside again to protect the velcro and roll the band up.