Precautions

- DO NOT expose the product to liquids or moisture
- DO NOT attempt to tamper with the product by dropping, disassembling, opening or scratching etc.
- DO NOT store the product near acidic or alkaline material
- Take out the headphones before washing
- Keep the product away from fire
- Note: when not used for 3-6 months, charge once.

Features

- Built-in microphone and wireless speakers
- Headphones are removable for washing
- Rechargeable through universal micro USB cable

Specifications

• Wireless version: V5.0

• Frequency: 2.402 GHz - 2.480 GHz

• Transmission range: 10m/33Ft

• Rated power: RMS 10mW x 2

• Speaker unit: 32 Ω/30mm

• Battery: 3.7V 180mAh rechargeable Li-polymer battery

• Standby time: over 120 hours

• Play time: over 12 hours

• Charge time: 2 hours



Wireless Sleep Headphones User Manual



Wireless Technology



Compatible with all Smartphones



Rechargeable Battery



Built-in Microphone

Control Buttons

Power On / Off	▶II) > 3 s	Press and hold for 3 seconds
Play / Pause Music	▶II) x 1	Press once when connected
Volume Up / Down	- +	Press and hold during music playback
Next Track	(+) x 1	Press once during music playback
Previous Track	— x 1	Press once during music playback
Answer/End Phone Call	▶II) x 2	Quickly press twice

Washing the SnoozeBand

- Carefully remove both ends of the speaker module using the opening inside the SnoozeBand
- Hand wash with cold water and air-dry
- Reinstall the wireless speaker module back to its original location. Make sure the buttons are aligned with the control panel.

Turning On/Off






Press and hold for 3 seconds

Pairing with your device





Connect to BT-Music on your device








LED Status Colour	Meaning
Rapidly flashing blue and red	Pending to be paired
Slowly flashing blue	Connected to a device

Charging



USB charging port

Plug the USB cable into a USB charging port or laptop. It will take about 1 hour to fully charge.

LED Colour	Meaning
Red	Charging
Blue	Fully charged